



DURA BIKE LOCKER

A DIVISION OF HANNAN SPECIALTIES INC.

Made in the USA

Wheel Chair Locker Assembly Instructions




www.durabikelocker.com

3790 BRADVIEW DR. - SACRAMENTO, CA 95827


(916) 363-7225 / (800) 722-BIKE (2453)

DURA WHEEL CHAIR LOCKER® ASSEMBLY INSTRUCTIONS


1. **Locate a Frame and Door:** Start by locating a frame and door.




2. **Front Frame:** Now stand up the frame (louvers at the top).




3. **Exterior Wall:** Next locate an exterior wall (these are painted/powder coated walls). Attach the wall to the frame using (5) pan head screws insuring the painted side faces the outside of the bank of lockers and is flush with the frame.




4. **Back Panel:** The back panel should be installed next. Stand up the panel and position it on the other end of the wall and attached it using (5) pan head screws. You should now have a frame, a wall, and a back panel standing ready for the next wall.




5. **Interior Wall:** For bank configurations locate a galvanized (non-painted) interior wall, for single standalone units locate the other painted wall. Position the wall between the frame and back panel you have already setup. For bank configurations insert a splice plate between the frame and wall (this links the lockers in the bank giving them more stability/rigidity) and secure the wall to the frame using (5) pan head screws. Next secure the wall to the back panel using (5) pan head screws, insuring both splice plates are aligned and sandwiched between the panels if you are installing these as a bank.



6. **Top:** The locker top can now be installed (we recommend using two people to carry these panels as they are very heavy) lift the top over the frame, back panel, and walls you have assembled in the previous steps. Slide a splice plate between the top and wall (this supports the top of the next locker in the bank). Now from inside the locker attach the frame, back panel, and walls to the top using (26) pan head screws; (4) for each wall, (7) for the frame and (7) for the back panel.




7. **Padlock Handle:** Next the Padlock Handle can be installed. Put the shaft of the padlock handle through the punch in the door and secure the handle using (4) one-way security screws and (4) nylock nuts.




8. **Upper Lock Bar Prep.:** Now the CAM and lock bars can be installed. The upper lock bar must be inserted into the guide at the top of the door before the CAM can be installed.




9. **Lock CAM:** The CAM slides onto the padlock handle shaft after a nylon washer (.75 OD x .50 ID x .06 THK), insure the orientation of the CAM is correct otherwise the unit won't lock properly. Next secure the CAM using a zinc washer (.438 ID x 1 OD x .083 THK) and cotter pin (bend the legs of the cotter pin once inserted to keep it snug).




10. **Upper Lock Bar:** The lock bars can be attached at this point. Link the upper lock bar you slid into the door (step 12) to the CAM using (1) pan head screw (#10-24 x 1" zinc plated), (1) nylon washer (.5 OD x .266 ID x .06 THK, this get sandwiched between the CAM and lock bar), and (1) nylock nut.




11. **Lower Lock Bar:** Now install the lower lock bar by sliding it through the guide on the bottom of the door then link it to the CAM using (1) pan head screws (#10-24 x 1" zinc plated), (1) nylon washer (.5 OD x .266 ID x .06 THK, these get sandwiched between the CAM and lock bar), and (1) nylock nut.



12. **Continue the Bank:** The rest of the bank can now be constructed, continue by locating another frame then attach it to a splice plate (just as you would a wall). Repeat this on the opposite end of the locker with the back panel. The rest of the locker can be assembled by repeating steps 5-13. Finish the remaining lockers until you reach the end of the bank configuration (using a painted wall at the end).




13. **Finishing:** Now that the lockers are completely assembled ensure all screws are tight and all panels are flush. If anchoring is desired continue to the next step, otherwise enjoy your new Dura Lockers!



14. **Anchoring:** The bank configuration can be anchored to the concrete using the provided (4) redheads.


- a. Anchors are placed in four corners of the bank.



- b. Line up a Hammer Drill with a 3/8" bit suitable for concrete and drill a hole through the frame into the concrete.



- c. Next the frame can be anchored to the ground, ensure the redhead is straight not crooked when inserting it through the frame into the hole you drilled. Using a hammer, pound the redhead into the ground (make sure you already have the nut on your redhead before you begin hammering as they tend to mushroom where struck). Be careful not to strike the locker, once the redhead is secure tighten the nut to anchor the locker in place (do not over tighten as it could bend the frame and damage the locker).



END